

Introducing our *NEW* Line of *FirstCall™* Mortuary Products



All FirstCall™ Products
Made In U.S.A.



Magna Ultra Tuff © FirstCall™ Pouch

Full length pouch design with openings for webbing attachment to the cot and HD Nylon Zipper w/dual pulls

Made of Magna Ultra Tuff © Heavy Duty Stain Resistant Nylon Fabric coated with polyurethane for moisture protection

420 Denier nylon inner liner to further enhance durability

Document pouch with Velcro closure to protect paperwork

Designed to fit standard mortuary cots like our FCALL-COT-100 (as shown)

Available in Burgundy, Navy Blue, Hunter Green and Black

Part No	Description	Color	Qty/Cs	Lbs/Cs	Kg/Cs
FCALL-200-85	24 x 74 x 14" Ultra Tuff FirstCall™ Pouch	Burg	1	6	2.3

FirstCall™ Cover

20 x 76 x 14 brushed plush poly fabric

Polyurethane backing for easier cleaning

With or without elastic at the ends

Customized embroidery on one or both sides

Document pouch with Velcro closure

Available in Burgundy, Navy Blue and Hunter Green



Part No	Description	Color	Qty/Cs	Lbs/Cs	Kg/Cs
FCALL-CVR-85	20 x 76 x 14" Brushed Poly FirstCall™ Cover	Burg	1	2	.8



FirstCall™ Church Truck Drape

23 x 64 x 23 Brushed Fleece Nylon Fabric

Fits most church trucks

Even pleating with reinforced holes

Available in Burgundy

Part No	Description	Color	Qty/Cs	Lbs/Cs	Kg/Cs
FCALL-DRAPE-85	23 x 64 x 23" Brushed Poly FirstCall™ Drape	Burg	1	3	1.5



Medicalproducts Ltd. Eagle Pass TX 78852

Toll Free: (800) 345-2922 Fax: (800) 372-5649 Ph: (678) 413-9200

Internet Site: www.medicalproducts.com

Email: sales@medicalproducts.com

A Service Disabled Veteran Owned Company

Introducing our *NEW FirstCall™* Multi-Level One Man Mortuary Cot



All FirstCall™ Products Made In U.S.A.

- Multi-level locking positions and roll-in style allows one person to easily perform retrieval
- Special release makes it simple to raise/lower cot without assuming full weight of cot and body
- Load end legs unfold and lock automatically when unloading the cot and fold again when loaded into vehicle
- Can act as 2-wheeled stretcher when undercarriage is folded and locked making it highly maneuverable in tight areas
- Slides down stairs with built-in stair guides
- Multi-level feature allows the body to be moved easily to and from cot
- Quick-release restraints hold body in place in all areas
- Waterproof mattress makes it easy to clean
- 5" back end tires allow cot to roll in all areas
- Front and Back end locks at 6 different heights while raising/lowering
- Length: 76" (194 cm) Width: 20" (52 cm) Hgt: 32" (81 cm) Wgt: 62 lbs (28 kg)
- Load Cap. 450 lbs (205 kg)

Part No	Description	Color	Qty/Cs	Lbs/Cs	Kg/Cs
FCALL-COT-100	20 x 76" Multi Level FirstCall™ Mortuary Cot	Burg	1	62	28



FirstCall™ Church Truck

Features 6" wheels and three locking frame positions
 Extends to 48" length
 Constructed of anodized rectangular aluminum tubing
 Max load capacity : 1,000 Lbs (454 kg)
 Available in Silver, Gold or Bronze
 Structural 2 year warranty

Part No	Description	Qty/Cs	Lbs/Cs	Kg/Cs
CHTRK-100	4' FirstCall™ Church Truck	1	40	18.2



Medicalproducts Ltd. Eagle Pass TX 78852

Toll Free: (800) 345-2922 Fax: (800) 372-5649 Ph: (678) 413-9200

Internet Site: www.medicalproducts.com Email: sales@medicalproducts.com

A Service Disabled Veteran Owned Company